

FENDER "PRO-AMP" LAYOUT

MODEL 5E5-A

J-EE

NOTICE

VOLTAGES READ TO GROUND
WITH ELECTRONIC VOLTMETER
VALUES SHOWN + OR - 20%

